

Contents

Updated: 03.15.18

Introduction

Initialization

ZQ Calibration

VrefDQ Calibration

Read/Write Training

. Why Training?

. Write Leveling

. MPR Pattern Write

. Read Centering

. Write Centering

Periodic Calibration

In a Nutshell

Reference

DDR4 SDRAM – Initialization, Training and Calibration

Introduction

When a device with a [DRAM sub-system](#) is powered up, a number of things happen before the DRAM gets to an operational state. The following state-machine from the [JEDEC specification](#) shows the various states the DRAM transitions through from power-up.




Figure 1: DDR4 State Machine

In essence, the initialization procedure consists of 4 distinct phases

- Power-up and Initialization
- ZQ Calibration
- Vref DQ Calibration
- Read/Write Training (a.k.a Memory Training or Initial Calibration)

To better understand the following sections, let's assume you have a system which looks like this - An ASIC/FPGA/Processor with 1 DIMM module.




Figure 1: Example System

Initialization



Figure 2: Initialization States

Power-up and initialization is a fixed well-defined sequence of steps. Typically, when the system is powered up and the controller in the ASIC/FPGA/Processor is removed out of reset, it automatically performs the power-up and initialization sequence. Here's a super-simplified version of what the controller does. For exact details refer to section 3.3 in the [JESD79-49A specification](#).

1. Apply power to the DRAM
2. De-assert **RESET** and activate ClockEnable **CKE**
3. Enable clocks **CK_t/CK_c**
4. Issue **MRS** commands and load the Mode Registers [The mode registers are loaded in a specific sequence]
5. Perform ZQ Calibration [**ZQCL**]
6. Bring the DRAM into **IDLE** state

At this point the DRAMs on the DIMM module understand what frequency they have to operate at, what

the CAS Latency (CL), CAS Write Latency (CWL) and few other timing parameters are.

☛ Check out the article on [DDR4 timing parameters](#) to learn more about CL, CWL, etc ...

ZQ Calibration




Figure 3: ZQCL

ZQ Calibration is related to the data pins [DQ]. To understand what ZQ calibration does and why it is required, we need to first look at the circuit behind each DQ pin. Remember, the DQ pin is bidirectional. It is responsible for sending data back during reads and receiving data during writes.




Figure 4: DQ calibration block

Now, if you look within a DRAM, the circuit behind every DQ pin is made up of a set of parallel 240Ω resistor legs, as shown in Figure 4. Because of the nature of CMOS devices, these resistors are never exactly 240Ω. The resistance is even affected due to voltage and temperature changes. So, they are made tunable.

In order to tune these resistors to exactly 240Ω, each DRAM has


- a special block called **DQ calibration control block** and
- a **ZQ** pin to which an external **precision (+/- 1%) 240Ω** resistor is connected.

This external precision resistor is the "reference" and it remains at 240Ω at all temperatures. When a **ZQCL** command is issued during initialization, this DQ calibration control block gets enabled and it produces a tuning value. This value is then copied over to each DQ's internal circuitry.

Ok, the above explanation is a quick overview of ZQ calibration. If you're satisfied, proceed to the next section. If you're itching for more details, read on.

The 240Ω resistor leg within a DQ circuit is a type of resistor called "Poly Silicon Resistor" and is, typically, slightly larger than 240Ω (Poly silicon resistor is a type of resistor that is compatible with CMOS technology). There are number of p-channel devices that are connected in parallel to this poly-resistor so that it can be tuned exactly to 240Ω.

The figure below zooms into one 240Ω leg of the DQ circuit and shows 5 p-channel devices connected to the poly-resistor. These little transistors are set based on input **VOH[0:4]**.






Figure 5: DQ driver/receiver circuit [Source: Micron datasheet]

Now, the circuit connected to the DQ calibration control block is essentially a resistor divider circuit with one of the resistors being the poly and the other is the precision 240Ω. When a `ZQCL` command is issued during initialization, this DQ calibration control block is enabled and an internal comparator within the DQ calibration control block tunes the p-channel devices using `VOH[0:4]` until the voltage is exactly $VDDQ/2$ (A classic resistor divider). At this point the calibration has been complete and the `VOH` values are transferred all the DQ pins.




Figure 6: DQ calibration block [Source: Micron datasheet]

Next, you may wonder why the DQ pins even have this parallel network of 240Ω resistors in the first place!

Having a bank of parallel 240Ω resistors allows you to tune the drive strength (for READs) and termination resistance (for WRITES). Every PCB layout is different so this tuning capability is required to improve signal integrity, maximize the signal's eye-size and allow the DRAM to operate at high-speeds.


The signal drive strength from the DRAM can be controlled by setting mode register `MR1[2:1]`. The termination can be controlled using a combination of `RTT_NOM`, `RTT_WR` & `RTT_PARK` in mode registers `MR1`, `2` & `5` respectively.

Subscribe

Get notified when a new article is published!



Vref DQ Calibration

Figure 7:
VrefDQ
Calibration

In DDR4 the termination style of the data lines [DQ] was changed from CTT (Center Tapped Termination, also called SSTL Series-Stud Terminated Logic) to POD (Pseudo Open Drain). This was done to improve signal integrity at high speeds and to save IO power. This is not the first of its kind, GDDR5 (the graphics DRAM) uses POD as well.





Figure 8: SSTL in DDR3 vs POD in DDR4 [Image Source: Micron handbook]

What this means is, in DDR3 $V_{dd}/2$ is used as the voltage reference to decide if the [DQ] signal is 0 or 1. Take another look at the left-hand side of Figure 8, the receiver is essentially a voltage divider circuit.


But in DDR4 there is no voltage divider circuit at the receiver. It instead has an internal voltage reference which it uses to decide if the signal on data lines [DQ] is 0 or 1. This voltage reference is called V_{refDQ} . The V_{refDQ} can be set using mode registers MR6 and it needs to be set correctly by the memory controller during the V_{refDQ} calibration phase.

Read/Write Training

At this point the initialization procedure is complete and the DRAMs are in IDLE state, but the memory is STILL not operational. The Controller and PHY have to perform a few more important steps before data can be reliably written-to or read-from the DRAM. This important phase is called *Read/Write Training* (or Memory Training or Initial Calibration) wherein the controller (or PHY)

1. Runs algorithms to align clock [CK] and data strobe [DQS] at the DRAM
2. Runs algorithms and figures out the correct read and write delays to the DRAM
3. Centers the data eye for reads
4. Reports errors if the signal integrity is bad and data cannot be written or read reliably

This section is about the following circle in the state machine

Figure 9:
Read/Write
Training State

Why is Read/Write Training Required?

Let's take a closer look at our example system. The picture below shows how the *data signals* and *address/command signals* are connected between the ASIC/Processor and the DRAMs on the DIMM.

- The Data and DataStrobe [DQ & DQS] are connected to each memory in a *star topology* because each memory is connected to a different portion of the 72 data lines
- The Clock, Command & Address lines [A, CK, CKE, WE, CSn] on a DIMM are connected using a technique called *fly-by routing* topology. This is done because all DRAMs on the DIMM share the same address lines and fly-by routing is required to achieve better signal integrity and the high speeds.




Figure 10: Example System in Detail

So, from the ASIC/Processor's point of view each DRAM memory on the DIMM is located at a different distance. Or from the DIMM's point of view, the skew between clock and data is different for each

DRAM on the DIMM.

The DRAM is a fairly dumb device. Say you intend to do a **WRITE** operation, during initialization you tell the DRAM what the **CAS Write Latency** is by programming one of its Mode Registers (**CWL is the time delay between the column address and data at the inputs of a DRAM**), and you have to honor this timing parameter at all times. The memory controller needs to account for the board trace delays and the fly-by routing delays and launch Address and Data with the correct skew between them so that the Address and Data arrive at the memory with **CWL** latency between them.

For example, if you program the **CAS Write Latency** to **9**, once the ASIC/uP launches the Column Address, it will need to launch the different data bits at different times so that they all arrive at the DRAMs at a **CWL** of **9**.

Something similar to the above needs to be done for **READs** as well. Since each DRAM on the DIMM is located at a different distance, when a **READ** is issued each DRAM on the DIMM will see the **READ** command at different times and subsequently the data from each DRAM arrives at the ASIC/Processor at different times. During Initial Calibration, the ASIC/Processor figures out what the delays from each of the DRAMs are and trains its internal circuitry accordingly so that it latches the data from the various DRAMs at the right moment.

For Read/Write Training, the Controller/PHY IPs typically offer a number of algorithms. The most common ones are:

1. **Write Leveling**
2. **MPR Pattern Write**
3. **Read Centering**
4. **Write Centering**

All the above algorithms are performed by the memory controller and usually require you to only enable/disable each algorithm through a register and take action in case failures are reported. The following sections go into more detail about what the controller does when you enable each of these algorithms.

Write Leveling

When writing to a DRAM an important timing parameter that cannot be violated is **tDQSS**. **tDQSS** is the position of the DataStrobe (**DQS**) relative to Clock (**CK**). **tDQSS** has to be within a **tDQSS(MIN)** and **tDQSS(MAX)** as defined in the spec. If **tDQSS** is violated and falls outside the range, wrong data may be written to the memory.

Since the Clock to Data/DataStrobe skew is different for each DRAM on the DIMM, the memory controller needs to train itself so that it can compensate for this skew and maintain **tDQSS** at the input of each DRAM on the DIMM.

When you enable write-leveling in the controller, it does the following steps:

1. Does an Mode Register write to MR1 to set bit 7 to 1. This puts the DRAM into write-leveling mode. In write-leveling mode, when the DRAM sees a DataStrobe (**DQS**), it uses it to sample the Clock (**CK**) and return the sampled value back to the controller through the **DQ** bus.
2. The controller then sends a series of **DQS** pulses. Since the DRAM is in write-leveling mode, it samples the value of **CK** using **DQS** and returns this sampled value (either a 1 or 0), back to the controller, through the **DQ** bus.
3. The controller then
 - looks at the value of the **DQ** bit that is returned by the DRAM
 - either increments or decrements the **DQS** delay and
 - launches the next set of **DQS** pulses after some time
4. The DRAM once again samples **CK** and returns the sampled value through **DQ** bus
5. Steps 2 to 4 are repeated until the controller sees a 0-to-1 transition. At this point the controller locks the **DQS** delay setting and write-leveling is achieved for this DRAM device.
6. Steps 2 to 5 are then repeated for each **DQS** for the whole DIMM to complete the write-leveling procedure
7. The DRAMs are finally removed out of write-leveling mode by writing a 0 to MR1[7]

The figure below shows the write-leveling concept.




Figure 11: Write Leveling

MPR Pattern Write

MPR (Multi Purpose Register) Pattern Write isn't exactly a calibration algorithm. It is typically a step that is performed before Read Centering and Write Centering.

DDR4 DRAMs contain four 8-bit programmable registers called MPR registers that are used for DQ bit training (i.e., Read and Write Centering). MPR access mode is enabled by setting Mode Register MR3[2] = 1. When this mode is enabled READS and WRITES issued to the DRAM are diverted to the Multi Purpose Register instead of the memory banks.




Figure 12: MPR Read/Write

Read Centering

The purpose of read centering is to train the internal *read capture circuitry* in the controller (or PHY) to capture the data in the center of the data eye. The memory controller (or PHY)

1. Enables bit 2 in mode register MR3 so that the DRAM returns data from the Multi Purpose Register (MPR) instead of the DRAM memory.
2. Then initiates a continuous stream of READS. The memory returns the pattern that was written in the previous MPR Pattern Write step. Let's assume this pattern is an alternating 1-0-1-0-...
3. While the READS are going on, the internal read capture circuitry either increases or decreases an internal read delay register to find the left and right edge of the data eye.
4. When the edges of the eye are detected, the read delay registers are set appropriately to ensure the data is captured at the eye center.
5. The above steps are repeated for each of the DQ data bits

Write Centering

Similar to the read centering step, the purpose of write centering is to set the write delay for each data bit so that write data is centered on the corresponding write strobe edge *at the DRAM device*.

During write centering the PHY does the following **WRITE-READ-SHIFT-COMPARE** loop continuously

1. Initiates a continuous stream of WRITES and READS
2. Incrementally changes write delay of the data bits
3. Compares the data read back to the data written

From the above loop the PHY can determine for what write-delay range it reads back good data, and hence it can figure out the left and write edges of the write-data eye. Using this data the DQ is centered to the DQS for writes.

Periodic Calibration

In a device such as a network switch or router, there could be changes in Voltage and Temperature during its course of operation. To keep the signal integrity and data access reliable, some of the parameters that were trained during initialization and read/write training have to be re-run. Memory controller and PHY IPs typically provide the following two periodic calibration processes.

- **Periodic ZQ** - Also known as ZQ Calibration Short (ZQCS). It is used to run ZQ calibration periodically to tune the 240Ω resistor that was described [earlier](#).
- **Periodic Read Centering** - To re-calculate read delays and other read related parameters

Enabling periodic calibration is optional because if you know your device will be deployed in stable temperature conditions, then the initial ZQ calibration and read/write training is sufficient.

Typically, the memory controller or PHY allow you to set a timer and enable periodic calibration through their registers. Once the timer is set, periodic calibration is run every time the timer

exhibits

In a Nutshell

There are 4 steps to be completed before the DRAM can be used

1. Power-up and initialization
2. ZQ Calibration
3. Vref DQ Calibration
4. Read/Write Training

Once this is done system is officially in IDLE and operational. You may need to enable periodic calibration depending upon the conditions in which your device is deployed.

Reference

- [JEDEC specification](#)
- [A number of Micron DDR4 Datasheets](#)
- [A number of Micron DDR3 Datasheets](#)
- [Rambus - Fly-By Topology](#)
- [AIC Design - Resistors and Inductors](#)
- [Bit-Tech](#)
- [EETimes](#)
- [JEDEC DDR4 Mini Workshop](#)
- [Cadence](#)
- [Texas Instruments](#)

Subscribe

Get notified when a new article is published ...

🔒 Promise you won't be spammed!

-.-'-